



CONVERSION UB8 PLAIN TILE VENT TO UB37 PLAIN TILE TERMINAL FIXING INSTRUCTION

For Soil & Vent Terminals & Mechanical Extract Terminals

1. Trim out the insect grille from the underside of the UB8.
2. Install the UB8 as per the fixing instructions ensuring that the vent is mechanically fixed to the batten. Using silicone on the inside of the adaptor to seal the joint, push the adaptor onto the back of the unit.

Ubbink UK Ltd, Unit 33 Liliput Road, Brackmills Ind Est,
Northampton, NN4 7DT
Tel: 01604 433000 Fax: 01604 433001
Email: info@ubbink.co.uk Web: www.ubbink.co.uk