



Issue 1

FIXING GUIDELINES FOR MULTIVENT 160 **(UB35)**

1. Complete tiling/slating to the course below where the Multivent is to be installed.
2. Make an 'X' cut in the underlay/sarking to allow for the penetration of the 160mm diameter pipe. In order to make the 'X' cut, it may be necessary to trim out a section of the existing support batten and then fit an additional batten above/below the cut batten.
3. Position the lead flashing over the cut in the underlay and dress the lead over the lower course of tiles/slates. Ensure lead is dressed carefully into profiled tiles. Dress the top edge on to the batten & turn up to form a lip.
4. Continue slating/tiling either side of the unit.
5. In the course above the terminal –
Tiles it may be necessary to cut the tile immediately above the unit
Slates the slates in this course need to be trimmed to allow for the unit
6. Engage pipe into base, ensuring cut sections of the underlay are pulled upwards
7. Secure pipe in vertical position with pipe clip.

Ubbink UK Ltd, Unit 33 Liliput Road, Brackmills Ind Est, Northampton, NN4 7DT

Tel: 01604 433000 Fax: 01604 433001

W: www.ubbink.co.uk E: info@ubbink.co.uk